



QUICK REFERENCE CLEANING GUIDE

CLEANERS & TOOLS

TYPE	RECOMMENDED CLEANING PRODUCT
Stainless Steel Cleaners	Norwex [®] cleaning paste*, ECOS [®] stainless steel cleaner and polish*, Haus Naturals [®] stainless steel cleaner*, Therapy Clean [®] stainless steel cleaner and polish*
Glass Cleaners	Windex [®] glass cleaners, Haus Naturals [®] Streak-Free Glass Cleaner*
Mild Detergents	Haus Naturals [®] all purpose cleaner*
Heavy Discoloration	Penny-Brite [®] , Copper Brite [®] , Paste Nu-Steel [®]
Cleaning Tools	E-Cloth [®] Microfiber Home Cleaning Set for Chemical Free Cleaning*, Scotch Brite [®] pink or blue sponges

* Green cleaning alternative

CLEANING STAINLESS STEEL

Remove food particles and stains first, by wiping down the stainless surfaces with a damp cloth, then dry the surface. Apply a stainless steel cleaner with a microfiber cloth. Make sure to wipe the surface dry after applying the cleaner. Once the surface is cleaned, apply a stainless steel polish to prevent future food stains and fingerprints.

** Do not soak any stainless steel parts- including the shelving, in water to clean. Instead, allow parts to come to room temperature and clean with a blue or pink Scotch Brite pad to remove stubborn stains.*

GLASS DOOR CLEANING

Wipe any food particles or stains from the window first, then clean window with a glass door cleaner and lint-free cloth till dry to avoid streaking. If streaking occurs, make a 50/50 ratio of white vinegar to distilled water and clean with a lint-free cloth.

TO CLEAN YOUR PAINTED SURFACES:

1. Carefully remove any loose sediment with a wet sponge.
2. Use a soft brush (non abrasive) or cloth, and a mild household detergent solution to remove dust, salt, and other deposits. Never use solvent-based cleaners, stainless steel cleaner, or heavy degreasers such as oven cleaner on the painted surfaces. These cleaners can permanently damage the paint.
3. Rinse off with clean fresh water and dry with a clean cloth.

INTERIOR CLEANING

First, remove all bins and shelves from the interior. Wipe the entire interior with a mild detergent solution and cloth. If any food particles or stains persist, use a blue or pink Scotch Brite pad to remove with the same mild detergent solution. Dry interior with a microfiber cloth.

Clean all the removed shelves and bins with the same mild detergent solution. DO NOT soak any parts to avoid any rusting or damage. Dry all parts with a microfiber cloth before reinstalling in the unit.

OUTDOOR AND MARINE GRADE PRODUCTS

Wipe down exterior surfaces daily with a microfiber cloth to remove any deposits and avoid any rusting.

Use the same cleaning products and steps as the indoor models.